

SOUND SYSTEM for VISITORS

Sound System

As of May 12, 2008, the cabinet is locked in response to changes made to the gain switches which affected every choir setting and caused serious problems including feedback. The choir directors have overwhelmingly agreed. Each choir has their settings saved on a unique channel.

Use by Visitors

Agreement to Use Equipment

1. If you use any equipment, you agree to use it at your own risk and agree to immediately repair or replace any equipment abused in any manner while in your care.

Microphones

2. Two microphones are available for your use.
 - a. They are located in the drawer below the counter, at the end of this room, farthest from the exit.
 - b. Microphone cords hang on the wall.
 - c. Microphone stands, music and guitar stands are also available.
3. Plug in all microphones into any available jack built into the facing on the choir risers.
 - a. Input jacks are numbered. The gain on #7 is set very high for use with the piano. Avoid using a microphone in #7.
 - b. Input jacks are all XLR type (3 wire) and are powered for use with condenser mics.

Sound System

4. The sound system has 99 preset channels. Use the 'midi mouse' to select a channel. Click on the left or right to change channels. (The 'midi mouse' is the small black box with silver push buttons on top of the sound system cabinet).

Use the left and right buttons on the midi mouse to select one of the following channels:

All inputs set to:	Overhead Mics OFF	Overhead Mics ON
HALF Volume	Channel 1	Channel 4
FULL Volume	Channel 2	Channel 5
MEDIUM Volume	Channel 3	Channel 6

5. When all microphones have been plugged in, turn on the sound system using the small rocker switch at the top/front of the black sound system cabinet. When the green light is on, the sound system is on. Turn the system off before unplugging.
6. If you experience any problems, like feedback, turn the system off immediately. Change the preset channel and try again.

On Completion

7. When finished, please turn off the system before unplugging any equipment, then replace all equipment neatly.

Thank you for treating our equipment with care!

St. Justin's Choirs